



Sailing Tips

September 2013

Alternative gennaker sheeting for lighter loads on the sheet.

Method one: Put a (non ratchet) turning block on the back edge of the tramp and take the gennaker sheet through the line as shown.



Method Two: Put a turning block on the front of the tramp as shown.

